

NS-002

N-Switch 4合1有线摇台

产品说明书




—专注于游戏开发制造—



产品适用说明

1. 本产品是一款4合1有线格斗摇台，适合用户在N-Switch/PS3/PC/Android电视上有线连接，进行游戏操作使用；
2. 操作方便，即插即用，通过USB插头直接向游戏主机取电并控制主机的游戏操作；
3. 支持TURBO连打功能，体验游戏“搓招”快感；
4. 适用于操作各类街霸格斗、马里奥系列、明星大乱斗等游戏；

产品外观接口图示



产品特性参数

1. 产品尺寸：L200*W150*H135mm；
2. 产品重量：400±5g；
3. 工作电压/电流：DC5V/20mA；
4. USB线：线长L=3m；

产品基本操作

1. 本产品功能操作简单，只需要将产品的USB插头接入N-Switch Dock/PS3/PC/Android电视的USB接口，产品指示灯亮起，便可以控制对应平台中的游戏操作！
2. 在连接N-Switch Dock进行游戏操作时，请确认N-Switch主机的系统设置中，‘Pro手柄的有线连接’处于开启状态；
3. 产品接入PC端，有D_INPUT和X_INPUT两种模式，同时长按‘-’‘+’键5秒，进行切换选择！

TURBO功能

1. 动作键包括(A/B/X/Y/L/R) 6个按键，均可手动设置TURBO功能；
2. 设置方式：长按动作键，再轻按TB键开启，长按动作键，再轻按TB键，TURBO功能关闭；
3. 产品休眠、关机重启后，之前设置TURBO功能自动清除，若启用TURBO功能时，必须重新设置！

产品维修卡

产品型号		生产日期	
用户姓名	电话	机身编号	
用户地址	省 市（县）	邮 编	
购买商品		购买日期	年 月 日

详细故障

注：请顾客填写清楚故障现象、发生故障时间、环境及发生故障时本机处的工作状态。

维修记录	日期	故障现象	处理方法	维修人员签字

NS-002

N-Switch 4 in 1 Wired Joystick

Product Instruction




—Focus on game development and manufacturing—



Scope of Application

- 1.This item is a wired joystick for fighting games, suitable for users to connect N-Switch/PS3/PC/Android to TV with wire and play games.
- 2.Easy operation, plug and play. Directly powered by the PlayStation through USB cable to realize controlling the game playing.
- 3.Support TURBO function, allowing users to experience much more fun from the game.
- 4.Suitable for all kinds of Street Fighter fighting games ,Mario Cart, Super Smash Bros. etc.

Product Interface



Product Parameter

- 1.Product Size：L200*W150*H135mm；
- 2.Weight：400±5g；
- 3.Working Voltage/Current：DC5V/20mA；
- 4.USB Cable：L=3m；

Basic Operation

- 1.This product is easy in operation,users just need to connect its USB port with the USB port of N-Switch Dock/PS3/PC/Android TV, with the indication light lights up, users can play the games in the platform accordingly.
- 2.Please ensure that the "Pro Controller Wired Communication" in the system settings of N-Switch has turn on when you are playing games after connecting to N-Switch.
- 3.Once this item has been connecting with PC, there will be two modes for option: D_INPUT and X_INPUT. Press both "-"and "+" at the same time for 5 seconds to switch option on the mode.

TURBO Function

- 1.There are 6 action keys(A/B/X/Y/L/R), all can achieve TURBO function by manual setting.
- 2.Setting method: Long press the action key, then flip the TB key to turn on. The same to turn off by long pressing the action key and then flipping the TB key.
- 3.Once the product restarts from sleeping mode or shut-down state, the TURBO function set before will be cleared automatically. If need to turn on the TURBO function again, the user need to do the settings once again.

Product Warranty Card

Product model		Date of production	
User name	Tele phone	Serial No	
User address	Province city	Zip code	
Prurchase goods		Purchase date	year month day

Detailed fault

Note:Please fill out the working condition of the macine when the fault phenomenon, the failure time,the environment and the fault occur

Maintenance records	Date	Fault Phenomenon	Processing method	Signature of maintenance personnel